


SUEZ CANAL

Phase 62 feet

CROSS SECTIONS


No. of Drawings: 8

Suez Canal Cross Sections
 (Phase 62 feet)



Cross Section at Km 6.737 - 8.400 E

H. Scale = 0.5 V. Scale




Cross Section at Km 6.000 - 16.450

H. Scale = 0.5 V. Scale




Cross Section at Km 19.000 - 30.190

Suez Canal Cross Sections
(Phase 62 feet)




Cross Section at Km 154.724 - 157.550 (Curve)




Cross Section at Km 159.900 (Curve)


Suez Canal Cross Sections
 (Phase 62 feet)



Cross Section at Km 145.915 (Garage)




Cross Section at Km 147.146 - 149.435




Cross Section at Km 149.400 - 153.524


Suez Canal Cross Sections
 (Phase 62 feet)



Cross Section at Km 125.507 - 128.899



Cross Section at Km 129.499 - 131.975 (Curve)



Cross Section at Km 134.543 - 144.715

Suez Canal Cross Sections
 (Phase 62 feet)



Cross Section at Km 96.000 - 97.695
 H. Scale = 0.5 V. Scale




Cross Section at Km 105.250 - 112.871
 H. Scale = 0.5 V. Scale




Cross Section at Km 115.603 - 122.100
 H. Scale = 0.5 V. Scale

Cross Section at Km 115.520 - 121.600
 H. Scale = 0.5 V. Scale

Suez Canal Cross Sections
 (Phase 62 feet)



Cross Section at Km 82.105 - 85.027



Cross Section at Km 85.027 - 87.414 (Curve)




Cross Section at Km 88.814 - 92.800

Suez Canal Cross Sections
 (Phase 62 feet)



Cross Section at Km 64.514 - 71.164




Cross Section at Km 71.964 - 75.311 (S - Curve)




Cross Section at Km 77.105 - 77.900 E (Curve)

Suez Canal Cross Sections
 (Phase 62 feet)



Cross Section at Km 32.350 - 32.950 (Garage)



Cross Section at Km 35.110 - 49.512



Cross Section at Km 54.098 - 56.397

Cross Section at Km 51.785 - 59.895 E

H- Scale = 0.5 V-Scale